




# CarouselUSA



## **Model 40SSV Surface Mounted Turntable Operation and Maintenance Manual**

Revised 6/29/2021

## MANUFACTURER'S LIMITED WARRANTY FOR CAROUSEL USA MODEL 40SSV

The limited warranty set forth below is given by Carousel USA with respect to new merchandise only.

"Carousel USA" warrants this product (excluding its *Normal Wear Parts* as described below) against defects in material and workmanship for a period of two (2) years commencing on the date of delivery to user and will, at its option, repair or replace, free of charge, any part found to be defective in materials or workmanship. This limited warranty shall only apply if this product has been operated and maintained in accordance with the Operator's Manual furnished with the product, and has not been subject to misuse, abuse, neglect, accident, improper maintenance, alteration, vandalism, theft, fire, water, or damage because of other peril or natural disaster. Damage resulting from the installation or use of any part, accessory or attachment not approved by Carousel USA for use with the product(s) covered by this manual will void your warranty as to any resulting damage.

***Normal Wear Parts*** are warranted to be free from defects in material and workmanship for a period of (1) one year from the date of delivery to user. Normal wear parts include, but are not limited to items including: support wheels, and pinion gears. ***Finishes warranty:*** this applies to finishes only; turntable components and structures with powder coat finishes, painted finishes, and hot-dip galvanized finishes. Given our inability to dictate how the finish is cared for, the finishes are warranted for; 5 years for hot-dip galvanized components; 6 months for painted or powder coated finishes.

**HOW TO OBTAIN SERVICE:** Warranty service is available, WITH PROOF OF PURCHASE, through Carousel USA.

Carousel USA  
15206 Ceres Avenue  
Fontana, CA 92335  
626-334-7190  
[www.carousel-usa.com](http://www.carousel-usa.com)

This limited warranty does not provide coverage in the following cases:

Routine maintenance items such as lubricants, drive adjustments, deck adjustments, running gear cleaning, and normal deterioration of the exterior finish due to use or exposure.

- a. Service completed by someone other than an authorized service dealer.
- b. Carousel USA does not extend any warranty for products sold or exported outside of the United States and/or Canada, and their respective possessions and territories, except those sold through Carousel USA's authorized channels of export distribution.
- c. Replacement parts that are not genuine Carousel USA parts.
- d. Transportation charges and service calls.

**No implied warranty, including any implied warranty of merchantability or fitness for a particular purpose, applies after the applicable period of express written warranty above as to the parts as identified. No other express warranty, whether written or oral, except as mentioned above, given by any person or entity, including a dealer or retailer, with respect to any product, shall bind Carousel USA. During the period of the warranty, the exclusive remedy is repair or replacement of the product as set forth above.**

**The provisions as set forth in this warranty provide the sole and exclusive remedy arising from the sale. Carousel USA shall not be liable for incidental or consequential loss or damage including, without limitation, expenses incurred for substitute or replacement turntable services or for rental expenses to temporarily replace a warranted product.**

Some states do not allow the exclusion or limitation of incidental or consequential damages, or limitations on how long an implied warranty lasts, so the above exclusions or limitations may not apply to you.

In no event shall recovery of any kind be greater than the amount of the purchase price of the product sold. **Alteration of safety features of the product shall void this warranty.** You assume the risk and liability for loss, damage, or injury to you and your property and/or to others and their property arising out of the misuse or inability to use the product.

This limited warranty shall not extend to anyone other than the original purchaser.

**HOW STATE LAW RELATES TO THIS WARRANTY:** This limited warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

**IMPORTANT:** Owner must present Original Proof of Purchase to obtain warranty coverage.

**Proprietary Information**

Carousel USA has proprietary rights on the information in this document. It is forbidden to copy, duplicate or disclose the information herein, in whole or in part, or make use of the information, unless permission has been previously obtained, in writing, from Carousel USA.

## Table of Contents

<b>1. SCOPE .....</b>	<b>3</b>
<b>2. INTRODUCTION.....</b>	<b>3</b>
<b>3. TECHNICAL DESCRIPTION .....</b>	<b>3</b>
A. MECHANICAL OPERATION .....	3
B. TABLE OF SPECIFICATIONS.....	3
<b>4. INSTALLATION.....</b>	<b>4</b>
A. GENERAL.....	4
B. GENERAL TURNTABLE INSTALLATION.....	4
<b>5. ELECTRIC MOTOR CONNECTIONS .....</b>	<b>18</b>
<b>6. MAINTENANCE.....</b>	<b>19</b>
A. SUMMARY OF MAINTENANCE SCHEDULE.....	19
B. VISUAL/AUDIBLE INSPECTION.....	19
C. CLEANING PROGRAM.....	19
D. TRACK LUBRICATION.....	20
E. CENTER BEARING LUBRICATION .....	20
F. PIN-GEAR LUBRICATION.....	20
G. GEARBOX .....	20
<b>7. MAINTENANCE LOG .....</b>	<b>21</b>
DATE .....	21
MAINTENANCE DESCRIPTION .....	21
NOTES.....	21
INITIALS .....	21

## 1. Scope

This manual provides a technical description, installation, and instructions for the general safety and maintenance of the *40SSV Turntable*.

## 2. Introduction

This turntable is designed with special features to fulfill system operation requirements as follows:

- Surface mounted turntable for installations not requiring a concrete pit
- Pin-gear drive system, providing accurate and consistent torque without slippage
- Tapered roller bearing; main center bearing
- Roller bearing support wheels manufactured by CUSA, and made from extruded Nylon 6/6 containing finely divided particles of MoS<sub>2</sub> offering enhanced load bearing capabilities and increased wear and friction resistance.
- ¾ HP, commercial quality, Nord motor and helical-worm gearbox

## 3. Technical Description

### A. Mechanical Operation

The rigid steel turntable is supported by and rotates on a heavy duty tapered roller bearing at the center axis and 30 support wheels on the outside of the turntable. The turntable is powered by a ¾ HP Nord gearmotor. The Gearbox output shaft is connected to a pinion gear. The pinion gear meshes with the grooves which span the perimeter of the turntable and rotates the turntable in either direction with reliable and consistent torque.

### B. Table of Specifications

Turntable Diameter	157 ½" [4000mm]
Turntable Height	3 ¼" [83mm]
Load Capacity	6,000 LB operating capacity
Top Surface	3/16" [4.8mm] Steel
Rotation Speed (CW & CCW)	0.3 to 1.2 RPM
Hardware	Grade 8.8 or equivalent


## 4. Installation

### A. General


Unload the turntable components from the shipping crate. Make note of any damage that may have occurred during transit. Contact Carousel USA immediately if there is significant damage during transit.

### B. General Turntable Installation


ITEM #	PART NAME	PART NUMBER	QTY PROVIDED
1	CENTER BEARING ASSEMBLY	CA-40SSV	1
2	TRACK LOCATOR	T2101-40SSV	10
3	REGULAR TRACK	T2100-40SSV	9
4	MOTOR TRACK	T2103-40SSV	1
5	TRACK CONNECTOR	T2102-40SSV	10
6	MOTOR LOCATOR	T2104-40SSV	2



ITEM #	PART NAME	PART NUMBER	QTY PROVIDED
7	PIE ASSEMBLY - MALE - FEMALE	PW-40SSV-MF	14
8	PIE ASSEMBLY - FEMALE	PW-40SSV-F	1
9	PIE ASSEMBLY - MALE	PW-40SSV-M	1
10	MOTOR AND DRIVE ASSEMBLY	MA-40SSV	1
11	MOTOR COVER	M7003	1
12	RAMP	RAMP-40SSV	10
13	RAMP HOLE COVER	RAMP-40SSV-C	30
14	CENTER PANEL	T6400-40SSV	1



ITEM #	PART NAME	DESCRIPTION	QTY PROVIDED
A	ANCHOR14134	SELF TAPPING ANCHOR 5/16" X 2-3/4"	16
B	WA516	5/16" FLAT WASHER	8
C	ANCHOR38334	3/8" x 3 3/4" CONCRETE STUD ANCHOR	24
D	HHCSM608	HEX HEAD CAP SCREW M6 X 8MM	64
E	SWAM6	SPLIT LOCK WASHER M6	64
F	SHCSM1035	SOCKET HEAD CAP SCREW M10 X 35MM	16
G	SHCSM1020	SOCKET HEAD CAP SCREW M10 X 20MM	16
H	HNUTM10	HEX NUT M10	32
I	SWAM10	SPLIT LOCK WASHER M10	40
J	WAM10	M10 FLAT WASHER	16
K	SCB-4M	ELECTRONIC CONTROL BOX 4M	1



TOOLS REQUIRED FOR INSTALLATION



HAMMER DRILL



SHOP VACUUM



GREASE GUN W/ LITHIUM COMPLEX TYPE II EP2 GREASE



3/8" X 6" MASONRY DRILL BIT



1/4" X 6" MASONRY DRILL BIT



METRIC SOCKETS 10, 17, 19MM



IMPACT DRIVER



METRIC IMPACT BIT SOCKETS 8MM



METRIC TEE-HANDLE KEYS 8MM (OPTIONAL)



NUT DRIVER BIT 5/16"



MISC. METRIC SPANNER WRENCHES 10, 17, 19MM



DEEP SOCKET (9/16")




3/8" DRIVE TORQUE WRENCH







### **Step 1: Floor Preparation and Center Bearing Layout**

A. Prepare the installation site ensuring the surface is **Smooth, Flat,** and in **Good Condition** to support the loads that will be applied to floor. **Floor Flatness height deviation shall be no more than 1/8"**. Smoothen any uneven cracks and surfaces where the center bearing and tracks will be placed with dry pack mortar, epoxy resin, etc. **Un-even surfaces will result in installation difficulties, unwanted noise, and premature wear.** Recommended diameter of smooth and flat surface to be a minimum of 150".


B. Place the center bearing/hub assembly in the exact center of turntable installation site.



**Step 2: Lay-out track parts and motor locators.** *At this time, the installer must appropriately locate the Motor Track (item 4) and place the part at the desired location keeping in mind where the motor/motor cover will be optimally placed. One thing to consider is where the vehicles will be shot for photography; locating the motor at 180 degrees from the camera location.* Lay out the Regular Tracks (item 3), Track locators (item 2), Motor locators (item 6), and track connectors (item 5) in the orientation as shown in the images below. After all components are set in place, fasten all parts with M6 x 8mm Hex Head Cap Screws and M6 lock washers (items D and E) Tighten all the M6 x 8mm screws to 5-6 ft-lb.




**Step 3: Anchoring Tracks and Center Bearing to the Floor-** Use the ¼" masonry bit with a hammer drill and bore holes into the floor at the given holes on the tracks (two holes per track segment) and center bearing (five holes). Do not drill any holes for the motor connectors at this time. The holes should be ½" deeper than the screw embedment (3.25" hole depth). Use a shop vac or compressed air to remove dust and floor particles while drilling. Insert the pointed end of the 5/16" anchors (item A) into the holes to fasten down the tracks and center bearing. Drive the screw *slowly*, allowing the threads to tap into the concrete. Ensure that all screws heads are screwed all the way down. If the screw heads protrude up too far, they will collide with the rotating turntable and cause damage to the equipment.




#### **Step 4: Install Pie Assemblies**


- A. Start with the **male pie assembly** (item 9) by laying the pointed end atop the center bearing and support wheels along the curved track. Align a center bearing plate hole with the pie by rotating the circular disc, then use a M10 x 20mm socket head cap screw and M10 lock washer (items I & G) to *loosely fasten* the parts together. **Do Not Tighten ANY of the center bearing/pie connection screws until all the pies are in place.**



- B. Proceed with the **male-female pie assembly** (item 7) on the left side of the first male pie. I.e., layout the pies in a counterclockwise fashion. Align the pies 3 studs with the corresponding holes on the adjacent pie, then by laying the pointed end atop the center bearing and support wheels along the curved track. Align the center bearing plate hole with the pie by rotating the circular disc, then use a M10 x 20mm socket head cap screw and M10 lock washer (items I & G) to *loosely fasten* the parts together. *Do not attempt to install the M10 screw before aligning the 3 pie studs.* **Do Not Tighten ANY of the center bearing/pie connection screws until all the pies are in place.**





- C. Repeat the previous step laying out the male-female pies in a counterclockwise fashion 13 times until only the female pie is left.







- D. Finally, lay the **female pie** from above aligning the 6 grooves on the female pie with the 6 studs. Push the female pie downwards until it is level with the 2 adjacent pies, then push the female pie inwards until the outer radius is concentric. Align the center bearing plate hole with the pie then use a M10 x 20mm socket head cap screw and M10 lock washer (items I & G) to Securely Fasten the parts together. Tighten the remaining M10 screws and torque to 25-30 ft-lb.



**Step 5: Install Pie Connecting Screws and Pie Alignment Spacing**— Align the pie connection holes and install the M10 x 35mm socket head cap screw, M10 flat washer, M10 lock washer, and M10 Hex nut (items F, H, I, J) through 2 pies. The flat washer should be placed In Between the two pies and is used as a spacer to properly set the pie gaps. Repeat and Loosely fasten each joint until all 16 connections are made with the hardware. Tighten the hardware in a crisscross and even pattern across the turntable joints and torque the M10 bolts to 20 ft-lb. See images below.





**Step 6: Install Center Panel** - Simply place the Center Panel (item 14) in the turntable center opening. No hardware is required.





**Step 7: Apply Grease to the Tracks** - Grease must be applied to the circular track to reduce wheel wear, noise, and vibration. Use a grease gun and apply a generous bead of grease along the outer perimeter of the tracks. This is where the support wheels roll along as the turntable rotates. Use lithium type II grease.

**Step 8: Install Motor and Drive Assembly**

- A. Loosen the (8) M12 hex nuts on the drive assembly and motor assembly units (highlighted in blue in the picture below). Move both base plates forward until the M12 studs positioned at the end of the slots. See image below for illustration. Tighten (2) of the previously loosened M12 hex nuts on each the drive and motor assembly, locking in the plate positions.







- B. Place the Drive and Motor Assembly on the mounting surface and locate using the motor locators (item 6). Align the (4) holes on the motor locators. Hold the motor and drive assemblies in place and bore the (4) holes into the floor using the  $\frac{1}{4}$ " masonry bit with a hammer drill. The holes should be  $\frac{1}{2}$ " deeper than the screw embedment. Use a shop vac or compressed air to remove dust and floor particles while drilling. Insert the pointed end of the  $\frac{5}{16}$ " anchors (item A) into the (4) holes. Drive the screw *slowly*, allowing the threads to tap into the concrete. Now that the drive assembly location is set, move onto drilling and installing the remaining (6) anchors on the motor and drive unit.








- C. Loosen the (8) M12 hex nuts on the drive assembly and motor assembly units again (highlighted in blue in the picture below) and slide the motor and drive assembly along the fixed plates (highlighted in green) all the way inwards until the pinion gear and turntable teeth meshes and bottoms out. Now move the same assemblies back outwards  $1/8''$  to give the pinion and turntable mesh backlash or clearance. Tighten the (8) M12 hex nuts on the drive and motor assembly to lock in the backlash adjustment. Torque M12 Nuts to 35-40 ft-lb.






- D. Tension and level the drive chain by rotating highlighted green hardware for height, and red hardware for in/out movement and tension. Adjust the height of the chain so that the two sprockets are parallel. Simultaneously adjust the tension of the chain until taut and it is difficult to squeeze tension out by hand. Install the motor cover after testing the drive unit and turntable operation.




**Step 8: Install the Ramps**

- A. Lay out the ramp pieces around the turntable. The center line of the motor cover should align with the seam of two ramps 180 degrees across the turntable. There should be a 1 3/4" gap between the motor cover and the ramps. See image below. Manipulate the ramps to achieve a 3/16" gap between the turntable and the inside edge of the ramps.



- B. Use the 3/8" x 3 3/4" concrete stud anchors (item C) to secure the ramp pieces that will only see regular use (see image below). Blue arrows indicate the ramp/s that will frequently be driven on. It is not required to anchor all the ramp pieces. Drill a 3/8" hole into the floor on the desired ramp sections. Again, use a shop vac to remove dust and floor particles while drilling. Install hole covers onto ramps (item 13) lining up the inclined planes.




Example: If car enters/exits here, then anchor the ramp pieces that will be used to transition the car. Typically, this means anchoring 2-3 ramps.

## 5. Electric Motor Connections

---

- The images below are the two possible ways to route the cord to the motor. Under ground conduit terminating under the motor cover (left), surface mounted cord passed through motor cover hole (right)



1. Plug the motor cord into the corresponding socket located on the control box pigtail
2. Plug the 120V input power cord into a proper 120V receptacle

## 6. Maintenance

### WARNING

**TO PREVENT INJURY TO MAINTENANCE PERSONNEL OR DAMAGE TO EQUIPMENT, ALWAYS VERIFY THAT NO EXTERNAL VOLTAGE IS SUPPLIED TO THE TURNTABLE AND THAT THE SAFE/OPERATE SWITCH IS IN THE SAFE POSITION PRIOR TO PERFORMING ANY MAINTENANCE WORK.**

**IF POWER MUST BE APPLIED FOR TEST PURPOSES, TAKE ALL THE STEPS THAT ARE NECESSARY IN ORDER TO AVOID INJURIES AS A RESULT OF ELECTRICAL SHOCKS AND MOVEMENT OF MECHANICAL UNITS.**

### A. Summary of Maintenance Schedule

	<i>Type of Maintenance</i>	<i>Recommended Time Period</i>
<b>B</b>	Visual/Audible Inspection	Weekly
<b>C</b>	Cleaning Program	As required
<b>D</b>	Track Lubrication	100 operating hours
<b>E</b>	Center Bearing Lubrication	100 operating hours or every 12 months
<b>F</b>	Pin-Gear Lubrication	100 operating hours
<b>G</b>	Center Bearing Seals Inspection	12 months
<b>H</b>	Gearbox Replace oil	N/A

### B. Visual/Audible Inspection

Inspect the motor, drive gear, electrical components, wiring and wire connections for signs of damage or wear. Continued monitoring of equipment appearance, noise, roughness, and vibration during operation can assist in early detection of poor or unsafe components, structural failure, or poor bearing performance. The operator should be very familiar with the typical operating conditions generated by the equipment. Investigate and resolve any noted changes.

### C. Cleaning Program

The turntable should be cleaned as often as operating conditions require. All outside/exterior surfaces of the turntable require no maintenance, other than what is cosmetically necessary. Compressed air should not be used to clean out particulate matter that may become trapped as airborne particles will adhere to the lubricated teeth if blown toward the inside. Do not expose the center bearing and support wheel seal areas to pressurized cleaning.

#### ***D. Track Lubrication***

**CAUTION:** Eye and lung protection is essential when using aerosol lubricants. Extreme caution must be exercised when working under and around rotating equipment. Do not place hands or feet inside or near the mechanical components of the turntable while the equipment is in motion. Disconnect the electrical power when working underneath the turntable's top surface.

The surface of the support wheels rides along flat plates of steel known as the track. Proper lubrication of this surface is important to reduce excessive wear on the wheel surfaces. Lubrication should occur at intervals of no more than 100 hours of turntable operation. A synthetic, non-petroleum-based product is recommended, such as **Mobil 1 Synthetic Grease** or similar.

#### ***E. Center Bearing Lubrication***

Lubrication of the bearing is recommended every 100 operating hours for relatively slow rotating or oscillating applications. Idle equipment should not be neglected. Grease dries out and "breathing," due to temperature changes, can cause condensation within the bearing. Whether used or not, the bearing should have grease introduced every 12 months. The bearing should then be rotated a few times to coat all surfaces with fresh grease. The bearing is filled with Red Lithium Complex type EP2 grease. Do not attempt to disassemble the bearing or remove the ball retaining plug.

#### ***F. Pin-Gear Lubrication***

The meshing action and usual position of the gear tends to purge the lubricant; thus, the gear should be greased frequently with a small amount of lubricant. A well-maintained gear will provide smooth, quiet, and long service.

#### ***G. Center Bearing Seals***

Seals should be inspected during routine maintenance as recommended by the designer, but the interval should not exceed 12 months. Check for tears, breaks, or other signs of damage. Depending on the lubrication frequency and protection, it may be necessary to clean some areas to conduct this inspection. Carefully remove any buildup of debris around the seal and lubricate the bearing. For the main bearing seal, there should be a small bead of grease around the seal edge indicating the bearing is receiving sufficient lubrication.

#### ***H. Gearbox***

The Nord gearbox attached to the drive motor is sealed for life and does **NOT** require oil changes.

## 7. Maintenance Log

<i>Date</i>	<i>Maintenance Description</i>	<i>Notes</i>	<i>Initials</i>